


Screening & Monitoring exercises


Roger Randriamampianina & Trygve Aspelien & Paulo Madeiros


→ Blacklisting of the observations: The LISTE NOIRE DIAP file





























Change of thinning distance for aircraft data

Steps:

- 1- Perform the screening with default namelist settings.
 - -- save the output NODE/log files.
- 2- Fetch/check out the namelist for screening.
 In Harmonie: HarmonieDA co nam/harmonie_namelists.pm; HarmonieDA co scr/Screening
- 2- Find the screening group called NAMSCC
- 3- Change the RFIND AIREP to 70000;
- 4- compare the NODEs/Logs and find out that the number of active aircraft data should be different.

In Harmonie: the logs are under: \$PERM/hm_home/daScreening/archive/log

```
Check ODB:
cd $PERM/hm_home/daScreening/20180819_12/odb_ccma/CCMA
dcagen -F -n -N 1
odbsql -q "SELECT obstype, codetype, statid, varno, vertco_reference_1@body FROM hdr, body WHERE obstype ==
5 :" -o test.dat
```

Open the test.dat

Activate use of TEMP radiosondes and blacklist all BUFR radiosondes (TEMP codetype=35) & (BUFR codetype=109) & (obstype=5)

Steps:

- 1- Perform the screening with default namelist settings.
 - -- save the output NODE/log files.
- 2- Fetch/check out the LISTE LOC file
 - -- in Harmonie, we use MARS data, so check out LISTE LOC.conv.mars
- 3- delete the line with "N 5 35", if it's present
- 4- add the following line: "N 5 109".
 - -- Pay attention to the length of each input by looking to the "xxx" on top of the file.
- 5- Perform new screening
 - -- compare the NODEs/Logs or check the ODB CCMA

In Harmonie: the logs are under:

\$PERM/hm_home/daScreening/archive/log

Check ODB:

cd \$PERM/hm_home/daScreening/20180819_12/odb_ccma/CCMA dcagen -F -n -N 1

odbsql -q "SELECT obstype, codetype, statid, varno, vertco_reference_1@body FROM hdr, body WHERE obstype

== 5 ;" -o test.dat

Open the test.dat

Use BUFR radiosondes at "10238" only between 700 and 400 hPa (BUFR codetype=109) & (obstype=5)

Steps:

- 1- Perform the screening with default namelist settings.
 - -- save the output NODE/log files.
- 2- Fetch/check out the LISTE LOC file
 - -- in Harmonie, we use MARS data, so check out LISTE LOC.conv.mars
- 4- add the following line: "N 5 109 10238 2 PROF2 700 400 1 0 1".
 - -- Pay attention to the length of each input by looking to the "xxx" on top of the file.
- 5- Perform new screening
 - -- compare the NODEs/Logs or check the ODB CCMA

In Harmonie: the logs are under:

\$PERM/hm_home/daScreening/archive/log

Check ODB:

cd \$PERM/hm_home/daScreening/20180819_12/odb_ccma/CCMA dcagen -F -n -N 1

odbsql -q "SELECT obstype, codetype, statid, varno, vertco_reference_1@body FROM hdr, body WHERE obstype

== 5 ;" -o test.dat

Open test.dat

Blacklist wind from BUFR radiosondes at "01400" (BUFR codetype=109) & (obstype=5) & (varno=3)

odbsql -q "SELECT obstype, codetype, statid, varno, vertco reference 1@body FROM hdr, body WHERE obstype

Steps:

- 1- Perform the screening with default namelist settings.
 - -- save the output NODE/log files.
- 2- Fetch/check out the LISTE LOC file
 - -- in Harmonie, we use MARS data, so check out LISTE_LOC.conv.mars
- 4- add the following line: "N 5 109 01400 3".
 - -- Pay attention to the length of each input by looking to the "xxx" on top of the file.
- 5- Perform new screening
 - -- compare the NODEs/Logs or check the ODB CCMA

In Harmonie: the logs are under:

\$PERM/hm home/daScreening/archive/log

Check ODB:

cd \$PERM/hm_home/daScreening/20180819_12/odb_ccma/CCMA

dcagen -F -n -N 1

== 5 ;" -o test.dat

Open test.dat

Your choice

What you would like to do? See if you succeed... Otherwise, let me (Roger) know.

Exercise 5(1): Preparation for observation monitoring using obsmon

on cca/ccb mkdir \$TEMP/training cd \$TEMP/training qsub /perm/ms/no/sbu/training/exercises/obsmon_training.job

Results end up in \$TEMP/training/obsmon/archive;

tar czvf archive.tgz archive; move it to your <your_ecgb_scractch>/training; untar it; Now you have the results under "<your_ecgb_scratch>/training/archive"

#Visualize ODB with Shiny on ecgate

1. Get obsmon from hirlam.org:

Be sure that you are under scratch or perm: "git clone https://git.hirlam.org/Obsmon obsmon" Or take the tar file from /scratch/ms/no/sbt/DACOURS/obsmon.tar, then follow the instruction in /scratch/ms/no/sbt/DACOURS/obsmon_on_ecgb.README.md

2. Install obsmon:

cd obsmon ./install --local-install


3. Set up a valid config.toml file.

This file tells obsmon where to find the experiments. Please take a look at the example file "config.toml.example" included with obsmon. (See next slide)

4. Finally, run obsmon:

./obsmon --launch

Exercise 5 (2): Preparation for observation monitoring using obsmon



You can save the results of your tests in different directories for comparison.

Exercise 6: Testing obsmon post-processor and visualization

```
# Extra
# Make a local copy of:
# /perm/ms/no/sbu/training/exercises/obsmon_training.job
# /perm/ms/no/sbu/training/exercises/include.ass-training
```

cp /perm/ms/no/sbu/training/exercises/obsmon_training.job \$TEMP/training/. cp /perm/ms/no/sbu/training/exercises/include.ass-training \$TEMP/training/.

Modify the variable config in \$TEMP/training/obsmon_training.job to \$TEMP/training/include.ass-training #Don't forget to change the access mod to this file, by "chmod 755 include.ass-training"

Modify \$TEMP/training/include.ass-training to only monitor e.g. AIRCRAFT

Move \$TEMP/training/obsmon/ if you want to keep it mv \$TEMP/training/obsmon \$TEMP/training/obsmon-orig

Submit modified job script qsub \$TEMP/training/obsmon_training.job

You should have only two files under: "obsmon/archive/ecma/2018081912/", for example.

Visualize it if you want. (see previous slides)

Exercise 7: Combined screening and obsmon exercise

It turned out that the example odb data sets comprise only assimilation of humidity from radiosonde observations. The task is to add assimilation of temperature, and wind.

Tips:

- -- Change the LISTE_LOC or LISTE_NOIRE_DIAP, so that it doesn't content any lines with "N 5".
- -- You can also choose the type of radiosonde to keep in the assimilation (Codetype: 35, 36, 135, 109)

To do this please refer to exercise 2 or 3 or 4 and 6: Fetch and modify /perm/ms/no/sbu/training/exercises/obsmon_training.sh

And visualize the modified screening results.